



**Serbco SA Pipe Size Guide:**

Standard Copper Size (mm)	PPR Size (mm)	ID PN10 (mm)	ID PN12.5 (mm)	ID PN16 (mm)
15	20		15.4	14.4
22	25		19.4	18
28	32	26.2		23.2
35	40	32.6		29
42	50	40.8		36.2
54	63	51.4		45.8
65	75	61.4		54.4
76	90	73.6		65.4
	110	90		79.8
108	125	102.2		90.8

**Serbco SA Pipe Wall Thickness:**

PPR Size (mm)	PN10/12.5 (mm)	PN16 (mm)
20	2.3	2.8
25	2.8	3.5
32	2.9	4.4
40	3.7	5.5
50	4.6	6.9
63	5.8	8.6
75	6.8	10.3
90	8.2	12.3
110	10	15.1
125	11.4	17.1

